


## LUNOS e<sup>90</sup> Quick Guide - **Switch Operation Manual**

(for code setting #9)



## LEVEL 1 VENTILATION




Unit operates in energy recovery mode.

**5m<sup>3</sup>/hr**

For use when external conditions are very uncomfortable (i.e. very cold winter night, very hot summer day). Unit operates very quietly with maximum energy recovery efficiency and supply fresh air at a low rate. Suitable for times of low activity when the room occupant is sleeping or when the room is empty.

## LEVEL 2 VENTILATION




Unit operates in energy recovery mode.

**10m<sup>3</sup>/hr**

For use when external conditions are not comfortable (i.e. cold winter day and night, hot summer day). Unit operates quietly with high energy recovery efficiency and supply fresh air at a steady rate. Suitable for times of medium household activity when people are active while in the room.

## LEVEL 3 VENTILATION



Unit operates in energy recovery mode.

**20m<sup>3</sup>/hr**

For use when larger amounts of fresh air are required (i.e. while many people are active within the room or while excess moisture is building up from showers). Units operate with slightly lowered energy recovery efficiency and supply fresh air at a high rate.

## SUMMER BYPASS MODE


**This is activated from Level 3 ventilation by switching the right hand side switch OFF and ON within 2 seconds.**

Unit operates in **VENTILATION** mode & **DOES NOT** operate in energy recovery mode.

**20m<sup>3</sup>/hr**

For use when external conditions are more comfortable than internal conditions (i.e. cool summer night after a very hot day, pleasant spring/autumn day). Unit operates without energy recovery and supplies fresh air at a high rate.

## Switching OFF the unit.



For use when the room will not be occupied for an extended period of time.

Unit does not operate.

